

## WHY CLIENTS CHOOSE MEIKO



# Winsbury shakes up milk market with new bottle wash system

**To boost its sustainability and save labour, Winsbury Dairy in Chirbury, near Montgomery chose a Meiko bottle washing system**

Before Meiko, explains Winsbury's Ellie Beavan, the dairy spent 'hours and hours' double handling returned milk bottles; pre-washing and rinsing in a sink before a second wash in a small glass washer.

Now the backlog has gone and "the bottles go straight into the Meiko bottle washer where they are washed, heated to 80 degC (sterilized) and come out dry."

The Dairy supplies farm fresh milk and milkshakes to the consumer and catering market using milk vending machines and sustainable glass bottles.

See over for details...





Continued from page 1

Winsbury uses a gentle slow pasteurizing process which it says, retains more calcium and other nutrients.

Ellie is passionate about the nutritional benefits of Winsbury milk.

**“We have had really great service, fantastic product and reliability from Meiko,” says Ellie. “The bottle wash system has made life a lot easier!”**

Farms choosing Meiko equipment can be assured that the washing results provide the highest level of hygiene, tested to DIN 10534. Meiko dishwashers deliver a high temperature wash and rinse to inactivate bacteria such as E-coli 0157 which is responsible for many instances of food poisoning.

The MEIKO system uses separate, sealed channels to first send wash fluid into the bottle, then separately, rinse aid. Specially designed nozzles spray the chemicals directly into the bottles, along with water, guaranteeing that the full power of the jet enters the bottle – ensuring that everything is hygienically cleaned.

For information about how MEIKO can help your business call 01753 215120, email [MeikoUK@meiko-uk.co.uk](mailto:MeikoUK@meiko-uk.co.uk) or visit our website [www.meiko-uk.co.uk](http://www.meiko-uk.co.uk)

## Meiko Bottle Washer System

- Use MEIKO M-iClean UM GiO dishwashers as bottle washers, simply by replacing the bottom wash arm with the BOTTLE WASH ADAPTER.
- Meiko machines have a theoretical capacity of 640 bottles per hour (competitor 480) and each Meiko rack can hold up to 16 bottles (competitor 8), so the Meiko system is much more productive.
- the Meiko Bottle Washer takes bottles up to 114mm wide (competitor 100mm) and up to 370mm tall.
- Can even be retrofitted for all M-iClean UM and UM+ GiO undercounter dishwashers from 2009.
- Provides the highest level of hygiene, tested to DIN 10534.
- Inactivates bacteria such as E-coli 0157.

